

Heel Protector Fitting and Sizing Instructions

Print out this instruction sheet (set Page Sizing to **Actual size**), and hold your heel against within the dotted line. Select the size that best matches your existing heel tip.

How to identify which style is what series:


Classic series: style # starts with a numerical number

Signature series: style # starts with letter "**S**" **Party Party series:** style # starts with letters "**PP**"

C series: style # starts with letter "C"

Salsera series: style # starts with letters "SERA"

Competitive Dancer series: style # starts with letters "CD"
Limited & Stiletto Heels Edition: style # ends with suffix "LEDSS"





Model P-382 (Ultra Slim)

fits: Classic 3" Slim Plated Heel, Limited & Stiletto Heels Edition 3.5" Stiletto/2.75" Stiletto/3" Slim, Competitive Dancers 2.5"/3" Stiletto Heel.



Model P-575 (Tango Stiletto) fits: Any Tango Heels, Limited & Stiletto Heels Edition 3.5" Black Plated Stiletto/3" Stiletto Heel.



Model P-5830

fits: Competitive Dancer series 2.5" Slim Heel, 2.75" Slim Heel.



Model P-3

fits: Classic series 2.75"/3.5" Flare Heel, Salsera series 3" Heel, Signature/Party Party/C series 2.75"/3.5" Flare Heel.



Model P-5059

fits: Salsera series 3" heel, Competitive Dancer series 2.5" Flare Heel & 3" Flare Heel, Classic series 3.5" heel, Signature/ Party Party/C series 3.5" heel.



Model P-12

fits: Classic series 2.5" heel & 3" heel (Model P12 will be replacing both Model P1 & P2).



Model P-2040

fits: Salsera series 2.5" heel, Signature/ Party Party/C series 2" Slim, 2.75" Flare & 3" Flare Heel.



Model P-387

fits: Classic series 1.3" heel.



Model PCI

fits: Signature/Party Party/C series 1.2" heel.



Model PPG

fits: Signature/Party Party/C series 2.5" heel.